



















EXPLANATION

- Walker River Access Points

Sensitive Species-Represents the area in which the true location of observed extents of sensitive species are considered to occur. The type of sensitive species are located in or near the buffer points. For spills that occur near or in sensitive species areas during business hours call (775) 684-2900. After hours call (775) 882-2790 or (775) 782-4360

-  100 meter buffer around observed location
-  1600 meter buffer around observed location
-  10,000 meter buffer around observed locations
-  USGS Realtime Site
-  Cities-Towns
-  County Seat
-  Ditch or Intermittent
-  Perennial
-  Railroads
-  Railroad Spurs
-  State Maintained Roads
-  Basin Boundary
-  Tribal Lands
-  State Park
-  County Boundaries

Waterbodies

-  Dry Lake
 Intermittent Waterbody
 Perennial Waterbody



Sources:
Nevada Division of Environmental Protection
Nevada Department of Transportation
Nevada Natural Heritage Program
U.S. Geological Survey
NOTE: This map is for reference only. It has not been verified for deterministic purposes